

2600N Series

N95 PARTICULATE RESPIRATORS

2600N95 – Medium/Large
2601N95 – Small

HandyStrap® with buckle, allows mask to hang around neck when not in use.

Cloth HandyStrap feels cool and comfortable.

Soft foam nose cushion for added comfort and no pressure points.

Dura-Mesh® shell resists collapsing in heat and humidity.

Softspun® lining for increased comfort and durability.

Available in two sizes, for most workers and OSHA compliance.



HANGS LOOSE!

HandyStrap allows mask to conveniently hang around neck. You'll find it's a convenient place to keep it when you're not using it. And during wear the elastic cloth strap feels comfortable and cool.

SOFT FOAM NOSE CUSHION.

Easier to wear and more all-day comfort for more of the work force. Contoured nose bridge with a soft foam nose cushion for comfortable seal. Comes without a metal noseband to adjust.

DURA-MESH SHELL LASTS LONGER.

The exclusive Dura-Mesh shell protects the filter media so it stays cleaner-looking longer. The shell also resists collapsing in hot, humid environments so the respirator holds its shape longer. The result is fewer respirators used and lower costs.

MOLDEX TECHNICAL SERVICE.

Moldex provides technical assistance including help with fit testing, a *Train-the-Trainer Program*, a manual on *How To Set-Up Your Respiratory Protection Program* plus a Toll-Free Technical Help line. Just call 800/421-0668 ext. 550, or 310-837-6500 ext. 550.

N95 PARTICULATE RESPIRATORS

2600N Series

2600N95 – Medium/Large
2601N95 – Small

APPLICATIONS:

⚠ WARNING TO USER

1. Follow all instructions and warnings on the proper use of this respirator and wear during all times of exposure. Failure to do so will reduce respirator effectiveness, wearer protection and may result in sickness or death.
2. Before use, the user must first be trained by the employer in proper respirator use in accordance with applicable safety and health standards for the contaminant and exposure level in the assigned work area.
3. The particulates and other contaminants which can be dangerous to your health include those which you cannot see, taste, or smell.
4. This product has not been sold with warnings or use instructions for personnel involved in healthcare or related situations, where there may be the possibility of contact with disease or biological hazards. If you are considering such uses, first call the Moldex Technical Service Dept., 800/421-0668 ext. 550 or 310/837-6500 ext. 550.

USE AGAINST:

1. Particulate aerosols free of oil.


DO NOT USE AGAINST:

1. Concentrations of contaminants which are unknown or are immediately dangerous to life or health.
2. Concentrations of particulates which exceed the maximum use concentration or 10 times the OSHA Permissible Exposure Limit, whichever is lower.
3. Gases, vapors, asbestos, paint spray, sandblasting, or particulate materials which generate harmful vapors.
4. Oil-based mists.

RESTRICTIONS:


1. This respirator does not supply oxygen and must not be used in atmospheres containing less than 19.5% oxygen.
2. Do not remain in contaminated area if any physical distress occurs, for example breathing difficulty, dizziness or nausea.
3. Leave contaminated area and replace respirator if it is damaged, distorted, a proper fit can not be obtained or breathing becomes difficult.
4. Do not alter, modify, or abuse this respirator.
5. Store unused respirators in box in a clean, dry, non-contaminated area.
6. Dispose of respirator according to your employer's policy and local regulations.
7. Dispose no later than thirty days after first use.
8. Use respirator before the "use by" expiration date printed on box.

NIOSH LABEL



DEPARTMENT OF HEALTH & HUMAN SERVICES
U.S. DEPARTMENT OF LABOR

MOLDEX/METRIC INCORPORATED
CULVER CITY, CALIFORNIA, U.S.A.
800/421-0668



THESE RESPIRATORS ARE APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS:

TC-	PROTECTION ¹	RESPIRATOR		CAUTIONS AND LIMITATIONS ²
		2600N95	2601N95	
TC-84A-0013	N95	X	X	A B C J M N O P

1. Protection
N95 Particulate Filter (95% filter efficiency level) effective against particulate aerosols free of oil; time use restrictions may apply

2. Cautions and Limitations
A- Not for use in atmospheres containing less than 19.5 percent oxygen.
B- Not for use in atmospheres immediately dangerous to life or health.
C- Do not exceed maximum use concentrations established by regulatory standards.
J- Failure to properly use and maintain this product could result in injury or death.
M- All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA, and other applicable regulations.
N- Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configurations as specified by the manufacturer.
O- Refer to user's instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
P- NIOSH does not evaluate respirators as surgical masks.

TECHNICAL SERVICE

For technical assistance, information, and training materials, call 800/421-0668 ext. 550 or 310/837-6500 ext. 550.

PACKAGING

15 Respirators per Box
12 Boxes per Case
180 Respirators per Case

LIMITED WARRANTY

IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. **Exclusive Remedies:** damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex, products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damage, or liability, direct, indirect, incidental, special, or consequential, arising out of sale, use, or misuse, or the inability to use products by the user.

DISTRIBUTED BY:

In Canada:
Pacesetter Sales & Associates
20 Arthur Hall Drive
Sharon, ON L0G 1V0
Tel: 905/478-8042 Fax: 905/478-8010
www.pacesettersales.com

MOLDEX-METRIC, INC.
10111 W. Jefferson Blvd.
Culver City, CA 90232
800/421-0668 310/837-6500
FAX 310/837-9563

www.moldex.com e-mail: sales@moldex.com
Moldex, HandyStrap, Dura-Mesh and SoftSpun are registered trademarks.
The Mesh Design is a trademark of Moldex.
U.S. Patents #D285,374, #D387,015, #4,384,577, #4,850,347, #5,970,585.
Made in the U.S.A. 9701-721 REV D 9/05

