

Respirator Locker®



HANDY TWO IN ONE STORAGE!

Respirator Locker® provides hygienic storage for respirators. It's a personal dispenser for workers required to travel to remote locations. Fits easily in employee lockers or work vehicles. Separate compartment permits storage of a used respirator during breaks, preventing premature disposal of respirators.

LESS WASTE, SAVES MONEY

Reduces employee waste from taking extra respirators for the day. Allows employer to track respirator usage. Saves time going to get fresh respirators. The result is fewer respirators used and lower costs.

EASY FIT, MORE COMFORT

Each Moldex® respirator has our exclusive Dura-Mesh® shell that protects the filter media, so it stays cleaner looking longer. The shell resists collapsing, even in heat and humidity so the respirator holds its shape longer. Model #2350 and #2850 also features an exhale valve that reduces hot air buildup. Workers stay cooler and comfortable longer. In addition Model #2850 has a special carbon layer that helps relieve workers of nuisance levels (less than OSHA PEL) of ozone and organic vapor odors. Suitable for most welding fumes.

N95 PROTECTION

NIOSH certified under 42CFR84 regulations to have a filter efficiency level of 95% against particulates free of oil up to 10x PEL.

APPLICATIONS

Hot, humid, dusty environments where tool stores are distant or workers are required to travel to remote locations, i.e. utilities, landscaping operations, survey or road crews, construction, agriculture, forestry operations, transportation operations, manufacturing facilities with sprawling plants.

FEATURES

- 100% PVC-Free.
- Allows employer to monitor respirator usage, reducing costs.
- Reduces worker time spent going to get new respirators.
- Handy supply for workers at field worksites.
- Provides each worker with hygienic storage and a personal supply of respirators.
- Separate chamber stores used respirator during breaks.
- Holds four or five masks per Locker.
- Reduces worker time spent going to get new masks.
- HandyStrap® allows mask to conveniently hang down around the user's neck when not in use.
- Locker keeps Model #2850 carbon layer fresh.
- Meets heat and flame resistance in accordance with ANSI/ISEA 110-2003 Section 7.11.1.



2236



2856



USE AGAINST (2250, 2350, 2236):

1. Particulate aerosols free of oil.

USE AGAINST (2850, 2856):

1. Particulate aerosols free of oil.
2. Nuisance levels (less than OSHA Permissible Exposure Limits) of Organic Vapor Odors and/or Ozone.

DO NOT USE AGAINST:

1. Concentrations of contaminants which are unknown, or are immediately dangerous to life or health.
2. Concentrations of particulates which exceed the maximum use concentration or 10 times the OSHA Permissible Exposure Limit, whichever is lower.
3. Gases, vapors, asbestos, paint spray, sandblasting or particulate materials which generate harmful vapors. This respirator is not approved for any vapors or gases, so when used against organic vapor odors and/or ozone do not exceed the OSHA Permissible Exposure Limit.
4. Oil-based mists.

RESTRICTIONS

1. This respirator does not supply oxygen and must not be used in atmospheres containing less than 19.5% oxygen.
2. Do not remain in contaminated area if any physical distress occurs, for example breathing difficulty, dizziness or nausea.
3. Leave contaminated area and replace respirator if it is damaged, distorted, a proper fit can not be obtained or breathing becomes difficult.
4. Prior to each use, carefully inspect the entire respirator, including filter media and strap/weld attachment area for tears and damage. Staple or strap/weld attachment perforations do not affect respirator performance.
5. Do not alter, modify, or abuse this respirator.
6. Store unused respirators in box/bag in a clean, dry, non-contaminated area.
7. Dispose of respirator according to your employer's policy and local regulations.
8. Dispose no later than thirty days after first use.
9. Use respirator before the "use by" expiration date printed on box/bag.
10. If used for welding, wear appropriate eye and face protection.

TECHNICAL SERVICE HELP LINE

For technical assistance, call Moldex Technical Service Department at +1 (310) 837-6500 ext. 512/550 or +1 (800) 421-0668 ext. 512/550.


MOLDEX-METRIC, INC.

10111 W. Jefferson Blvd. Culver City, CA 90232
 TEL: +1 (800) 421-0668 or +1 (310) 837-6500 FAX +1 (310) 837-9563
 www.moldex.com e-mail: sales@moldex.com


CANADIAN CUSTOMER SERVICE

TEL: +1 (310) 837-6500, Ext. 517
 FAX: +1 (310) 837-95633

Moldex, Ideas that wear well, HandyStrap, Ventex, Softspun, Dura-Mesh and Respirator Locker are registered trademarks of Moldex-Metric, Inc.
 The PVC-Free logo and the mesh design are trademarks of Moldex-Metric, Inc.
 U.S. Patents #D285,374, #D387,015, #D418, 410, #D389, 239, #6,076,698, #6,047,698, #5,149,468, #4,850,347 and #5,970,585
 Made in the U.S.A. 9701-718 REV F 12/09



Moldex-Metric, Inc.
 Culver City, California, 90232 U.S.A.
 +1 (800) 421-0668



THESE RESPIRATORS ARE APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS

TC-	PROTECTION ¹	RESPIRATOR			CAUTIONS AND LIMITATIONS ²
		2200N95	2300N95	2800N95	
84A-0327	N95	X			ABCJMNOP
84A-0328	N95		X		ABCJMNOP
84A-3002	N95			X	ABCJMNOP

1. Protection
 N95 Particulate Filter (95% filter efficiency level) effective against particulate aerosols free of oil; time use restrictions may apply

2. Cautions and Limitations
 A- Not for use in atmospheres containing less than 19.5 percent oxygen.
 B- Not for use in atmospheres immediately dangerous to life or health.
 C- Do not exceed maximum use concentrations established by regulatory standards.
 J- Failure to properly use and maintain this product could result in injury or death.
 M- All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA, and other applicable regulations.
 N- Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configurations as specified by the manufacturer.
 O- Refer to user's instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
 P- NIOSH does not evaluate respirators as surgical masks.

PACKAGING

2236 Respirator Locker® Display

- (3) 2250 Respirator Lockers and
- (3) 2350 Respirator Lockers
- (5) Masks per Locker
- (6) Lockers per Case

2250 Respirator Locker®

- (5) 2200N95 Masks per Locker
- (27) Lockers per Case

2350 Respirator Locker®

- (5) 2300N95 Masks per Locker
- (16) Lockers per Case

2856 Respirator Locker® Display

- (6) 2850 Respirator Lockers
- (4) Masks per Locker
- (6) Lockers per Case

2850 Respirator Locker®

- (4) 2800N95 Masks per Locker
- (16) Lockers per Case

LIMITED WARRANTY IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. **Exclusive Remedies:** damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damages, or liability, direct, indirect, incidental, special or consequential, arising out of a sale, use or misuse, or the inability to use products by the user.

⚠ **WARNING TO USER**

1. Follow all instructions and warnings on the use of this respirator and wear during all times of exposure. Failure to do so will reduce respirator effectiveness, wearer protection and may result in sickness or death.
2. Before use, the user must first be trained by the employer in proper respirator use, in accordance with applicable safety and health standards, for the contaminant and exposure level in the assigned work area.
3. The particulates and other contaminants which can be dangerous to your health include those which you cannot see, taste, or smell.
4. This product has not been sold with warnings or use instructions for personnel involved in healthcare or related situations, where there may be the possibility of contact with disease or biological hazards. If you are considering such uses, first call the Moldex Technical Service Dept., +1 (310) 837-6500 ext. 512/550 or +1 (800) 421-0668 ext. 512/550.

DISTRIBUTED BY:



Printed on Recycled Paper



MOLDEX
 Ideas that wear well.