



## RESPIRATOR LOCKER® WITH PREMIUM WELDING RESPIRATOR 2850 – WITH 2800N95 MASKS

Holds four masks per Locker.

Reduces worker time spent going to get new masks.

Handy supply for workers at field worksites.

Provides each worker with a hygienic supply of respirators.

HandyStrap® allows mask to conveniently hang around neck when not in use.

Locker keeps carbon fresh.



### HANDY TWO IN ONE STORAGE!

Respirator Locker provides hygienic storage for masks. The carbon layer in the masks stays fresh. It's a personal dispenser for workers required to travel to remote locations. Fits easily in employee lockers or work vehicles.

### LESS WASTE, SAVES MONEY.

Reduces employee waste from taking extra masks for the day. Allows employer to meter respirator usage. Saves time going to get fresh masks. The result is fewer respirators used and lower costs.

### EASY FIT, MORE COMFORT.

Each Moldex respirator has our exclusive Dura-Mesh® shell that protects the filter media so

it stays cleaner looking longer. Plus it resists collapsing in heat and humidity. The Ventex® valve reduces hot air buildup so workers stay cooler longer.

### N95 PLUS NUISANCE OV/OZONE RELIEF.

A special sorbent helps relieve workers of nuisance levels (less than OSHA PEL) of ozone and organic vapor odors. Suitable for most welding fumes. Fits easily under welding hoods. (It is the user's responsibility to check current OSHA regulations and applicable guidelines for welding applications.)

### HANGS LOOSE.

HandyStrap allows mask to conveniently hang around neck. So it's always ready for use. And the elastic cloth strap is more comfortable and cooler.

## APPLICATIONS

### ! WARNING TO USER

1. Follow all instructions and warnings on the proper use of this respirator and wear during all times of exposure. Failure to do so will reduce respirator effectiveness, wearer protection, and may result in sickness or death.
2. Before use, the user must first be trained by the employer in proper respirator use, in accordance with applicable safety and health standards, for the contaminant and exposure level in the assigned work area.
3. The particulates and other contaminants which can be dangerous to your health include those which you cannot see, taste, or smell.
4. This product has not been sold with warnings or use instructions for personnel involved in health care or related situations, where there may be the possibility of contact with disease or biological hazards. If you are considering such uses, first call the Moldex Technical Service Dept., 310/837-6500 ext. 550 or 800/421-0668 ext 550.

### USE AGAINST:

1. Particulate aerosols free of oil.
2. Nuisance levels (less than OSHA Permissible Exposure Limits) of Organic Vapor Odors and/or Ozone.

### DO NOT USE AGAINST:

1. Concentrations of contaminants which are unknown, or are immediately dangerous to life or health.
2. Concentrations of particulates which exceed the maximum use concentration or 10 times the OSHA Permissible Exposure Limit, whichever is lower.
3. Gases, vapors, asbestos, paint spray, sandblasting or particulate materials which generate harmful vapors. This respirator is not approved for any vapors or gases, so when used against organic vapor odors and/or ozone do not exceed the OSHA Permissible Exposure Limit.
4. Oil-based mists.

### RESTRICTIONS:

1. This respirator does not supply oxygen and must not be used in atmospheres containing less than 19.5% oxygen.
2. Do not remain in contaminated area if any physical distress occurs, for example breathing difficulty, dizziness or nausea.
3. Leave contaminated area and replace respirator if it is damaged, distorted, a proper fit cannot be obtained, you taste, smell or become irritated by contaminants, or breathing becomes difficult.
4. Do not alter, modify, or abuse this respirator.
5. Store respirator in sealed bag in a clean, dry, non-contaminated area.
6. Dispose of respirator, according to your employer's policy and local regulations.
7. Dispose no later than thirty days after first use.
8. Use respirator before the "use by" expiration date printed on box.

### MOLDEX-METRIC, INC.

10111 W. Jefferson Blvd.  
Culver City, CA 90232  
800/421-0668 310/837-6500  
FAX 310/837-9563

www.moldex.com e-mail: sales@moldex.com

Moldex, Respirator Locker, HandyStrap, Dura-Mesh and Ventex are registered trademarks. The Mesh Design is a trademark of Moldex.  
U.S. Patents #D285,374, #D389,239, #D387,015, #D418,410, #2,316,033, #2,398,267, #4,384,577, #4,850,347, #5,149,468, #5,970,585, #6,047,698, #6,076,698.  
Made in the U.S.A. 9701-792 REV C 9/05



## APPROVAL

 <b>MOLDEX/METRIC INCORPORATED</b> CULVER CITY, CALIFORNIA, U.S.A. 800/421-0668				
				THESE RESPIRATORS ARE APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS:
TC-	PROTECTION <sup>1</sup>	RESPIRATOR		CAUTIONS AND LIMITATIONS <sup>2</sup>
		2800N95	2801N95	
TC-84A-3002	N95	x	x	A B C J M N O P

**1. Protection**  
N95 Particulate Filter (95% filter efficiency level) effective against particulate aerosols free of oil; time use restrictions may apply.

**2. Cautions and Limitations**  
 A- Not for use in atmospheres containing less than 19.5 percent oxygen.  
 B- Not for use in atmospheres immediately dangerous to life or health.  
 C- Do not exceed maximum use concentrations established by regulatory standards.  
 J- Failure to properly use and maintain this product could result in injury or death.  
 M- All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA, and other applicable regulations.  
 N- Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configurations as specified by the manufacturer.  
 O- Refer to User's Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.  
 P- NIOSH does not evaluate respirators as surgical masks.

## TECHNICAL SERVICE

For technical assistance, information and training materials, call 800/421-0668 ext. 550 or 310/837-6500 ext. 550.

## PACKAGING

2850  
4 Masks per Locker  
16 Lockers per Case  
64 Masks per Case

## LIMITED WARRANTY

### IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. **Exclusive Remedies:** damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damage, or liability, direct, indirect, incidental, special, or consequential, arising out of sale, use, or misuse, or the inability to use products by the user.

### DISTRIBUTED BY:

#### In Canada:

Pacesetter Sales & Associates  
20 Arthur Hall Drive  
Sharon, ON L0G 1V0  
Tel: 905/478-8042 Fax: 905/478-8010  
www.pacesettersales.com