

8000 Series Paint Bucket Kit



YOUR FACE NEVER HAD IT SO COMFORTABLE

Everything the user will need for oil-free agricultural pesticides and spray painting. Respirator, facepiece, organic vapor cartridges, and prefilters-packed in a bucket with FREE hearing protection.

The Moldex® 8000 Series Respirator is made of soft durable material that conforms to the contours of your face. It seals comfortably and remains sealed, even while talking.

The facepiece and filters feature a low profile design that ensures excellent vision, and allows protective eyewear to be worn. The 8000 Series Respirator weighs less than other half-masks, and with the weight distributed evenly, there are no pressure points.

The 8000 was designed to be low maintenance. No inhalation valves to stock. Every snap-on cartridge comes with a new inhalation valve already installed. No gaskets and no yoke to worry about either.

FREE FOAM EARPLUGS

SparkPlugs® made of extra-soft, extra-light foam, they naturally seal the ear canal without pressure and gently conform for a perfect fit. They offer a high NRR 33, making them suitable for most industrial environments.



FREE BUCKET

A resealable bucket prolongs the life of the organic vapor cartridges and allows for clean storage for your respirator when not in use. Makes a great paint bucket as well!

APPLICATIONS

Paint spray and pesticide applications which are oil-free.

FEATURES

- 100% PVC-Free.
- 1 8000 Facepiece (Available in small, medium, and large).
- 1 Pair of 8100 Organic Vapors Cartridges.
- 1 Bag of 8910 N95 Prefilters (5 Pairs).
- 1 Pair of 8020 Retainers.
- 1 8000 Manual.
- 1 Pair of Free 6604 SparkPlugs® Foam Earplugs.



WARNING

Failure to follow all instructions on the proper use of this respirator may reduce respirator effectiveness, wearer protection and may result in sickness or death. For additional information refer to your supervisor and/or see bag or instruction manual or phone +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512/550.

IMPORTANT

The wearer must read the warning on packaging and the instruction booklet packed with each bucket for product usage guide, approval labels, fitting instructions and product use limitations. This information must be followed each time the respirator is worn. Misuse of this product may result in overexposure to contaminants and cause sickness or death. For more information and assistance on Moldex respirators, call Moldex at +1 (800) 421-0668 ext. 512/550 (USA only) or +1 (310) 837-6500 ext. 512/550.

PRE-INSPECTION

Inspect your respirator before and after wearing. Do not wear and return to your supervisor if:

1. Headstraps are torn, cut, or have lost elasticity.
2. Buckles or head cradle are missing, damaged or broken.
3. Facepiece is cracked, torn, distorted, dirty, or has holes.
4. Inhalation/exhalation valves are missing, torn, damaged, or not properly seated.
5. Cartridges are at the end of their service life, cracked, damaged, or not properly seated.

FITTING INSTRUCTIONS

1. Users must follow instructions each time respirator is worn.
2. OSHA regulation 1910.134 (f) requires that the user be fit tested.
3. Do not wear with any facial hair, such as beards, which may prevent a proper fit.
4. If you cannot obtain a proper fit, do not enter the contaminated area and see your supervisor.

TECHNICAL SERVICE HELP LINE

For technical assistance, call Moldex Technical Service Department at +1 (310) 837-6500 ext. 512/550 or +1 (800) 421-0668 ext. 512/550.

MOLDEX-METRIC, INC.

10111 W. Jefferson Blvd. Culver City, CA 90232
TEL: +1 (800) 421-0668 or +1 (310) 837-6500 FAX +1 (310) 837-9563
www.moldex.com e-mail: sales@moldex.com

CANADIAN CUSTOMER SERVICE

TEL: +1 (310) 837-6500, Ext. 517
FAX: +1 (310) 837-95633

Moldex, Ideas that wear well and SparkPlugs are registered trademarks of Moldex-Metric, Inc. The bright green color and the random color pattern are trademarks of Moldex-Metric, Inc. U.S. Patents #D326,540, #5,505,197 and #6,298,849
Made in the U.S.A. 8800-744 REV E 06/09

PACKAGING

8111KN Paint Bucket Kit-SM
8112KN Paint Bucket Kit-MED
8113KN Paint Bucket Kit-LG

1 Respirator per Bucket
8 Buckets per Case

SELECTION GUIDE

Check 8000 Selection Guide for full line of facepieces, cartridges, pre-assembled respirators with cartridges, filters and prefilters, and NIOSH approvals and limitations.

LIMITED WARRANTY IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. **Exclusive Remedies:** damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damages, or liability, direct, indirect, incidental, special or consequential, arising out of a sale, use or misuse, or the inability to use products by the user.



WARNING TO USER

Not for use against two-part isocyanate paints. This respirator helps to protect only against respiratory hazards as specified. Check that contents correctly match package, as labeled for hazard and facepiece size. Misuse, or failure to follow all instructions, and warnings may result in sickness or death. For proper use: see your supervisor, read instructions, see enclosed instruction booklet or phone Moldex +1 (800) 421-0668 ext. 512/550 (USA only) or +1 (310) 837-6500 ext. 512/550.

DISTRIBUTED BY:



MOLDEX
Ideas that wear well.