

Rockets®

Reusable Earplugs



NRR 27 PROTECTION

With an NRR 27 rating, the Rockets® earplugs provide serious protection for most noisy environments. Tested independently in an accredited laboratory to ANSI S3.19-1974.

GET A GRIP

Rockets® reusable earplugs are designed to give you a great grip. The easy grip handle lets them easily slip into the ear and it's brightly colored for compliance checks.

AIR CUSHIONED FOR COMFORT

The air bubble in the tip provides cushioned comfort for all-day wear. The soft, flexible flanges provide a superior seal and fit most size ear canals.

WASH AND WEAR AGAIN

Rockets® earplugs can be washed and reused. Each pair comes with a Pocket-Pak® carrying case to keep them clean when not in use. The smooth shape slides easily into your pocket. No sharp edges.

METAL DETECTABLE VERSION

Rockets® also come in a metal detectable version which has a new metal detectable cord. The bright blue color is perfect for food processing applications. The enclosed metal ball bearing eliminates any exposed metal. The ball bearing and cord are in separate holes so that the earplugs remain detectable even if the cord is removed. The earplugs are corded to prevent earplug loss.

FEATURES

- 100% PVC-Free.
- Independently tested NRR 27, with a new sound dampening additive.
- NRR 27 gives protection in most noisy environments.
- Now with metal detectable cord.
- Easy grip handle lets earplugs easily slip into ear.
- Air bubble in tip provides cushioned comfort.
- Earplugs can be washed and reused.
- Pocket-Pak® carrying case provides hygienic storage of plugs between uses.
- Available in corded, uncorded, and corded metal detectable models.
- The bright green color is a trademark of Moldex-Metric, Inc. and also provides easy compliance checks.



MOLDEX®
Ideas that wear well.

ATTENUATION DATA

Tested According to ANSI Specs S3.19-1974 Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	34.3	35.3	36.8	34.7	35.5	40.5	37.5	40.3	44.4	NRR 27	CSA AL
Standard Deviation (dB)	4.1	4.4	5.1	3.1	3.4	3.7	3.8	6.2	3.8		



WARNING TO USER

1. Rockets® Reusable Earplugs must be fitted and worn correctly to provide effective protection.
2. Wash or clean hands before use. Plugs should be routinely washed with mild soap and warm water.
3. **CAUTION:** Remove with a slow twisting motion to break the seal. Due to the tight seals, rapid removal may damage eardrum.
4. Use this laboratory-derived attenuation data for comparison purposes only. The amount of protection afforded in field use often is significantly lower depending on how the protectors are fitted and worn.
5. Failure to follow all instructions could result in hearing loss or injury.
6. Failure to obtain a proper fit will reduce effectiveness of hearing protectors and could result in hearing loss or injury.
7. Rockets must only be used as part of a hearing conservation program that complies with applicable local safety and health regulations.
8. Overprotection can be dangerous. The wearer must be able to hear warning signals.
9. Wearers with hearing loss should exercise extreme caution.
10. It is the employer's responsibility to ensure that the type of hearing protector and its NRR is appropriate for the user in their particular workplace.
11. Use caution when working around machinery or any other equipment to ensure neck cord does not become caught or entangled.
12. Failure to follow these warnings could result in serious injury or death.

MOLDEX TECHNICAL ASSISTANCE

Moldex provides all of the technical assistance required to set up a hearing protection program. For more information call +1 (800) 421-0668 ext. 512/550 or e-mail: sales@moldex.com or visit www.moldex.com.

MOLDEX-METRIC, INC.

10111 W. Jefferson Blvd., Culver City, CA 90232
Tel: +1 (800) 421-0668 or +1 (310) 837-6500 Fax: +1 (310) 837-9563
Email: sales@moldex.com www.moldex.com

Moldex Technical Service Department: +1 (800) 421-0668 or +1 (310) 837-6500
Ext. 512/550

CANADIAN CUSTOMER SERVICE

TEL: +1 (310) 837-6500, Ext. 517
FAX: +1 (310) 837-9563

Moldex, Ideas that wear well, Special Ops, Rockets and PocketPak are registered trademarks.
The bright green color is a trademark of Moldex-Metric, Inc. Made in U.S.A.
U.S. Patents #D411,105, #D427,304, #5,957,136 and #6,440,339
9701-713 REV J 09/09

PACKAGING

6400 Rockets®, Uncorded

50 Pairs per Box
4 Boxes per Case

6404 Rockets®, Corded in Bag

50 Pairs per Box
4 Boxes per Case

6405 Rockets®, Corded

50 Pairs per Box
4 Boxes per Case

6415 Rockets®, Metal Detectable, Corded

50 Pairs per Box
4 Boxes per Case

6420 Rockets®, with Optional Cloth Cord

50 Pairs per Box
4 Boxes per Case

6480 Rockets®, Special Ops™, Uncorded

50 Pairs per Box
4 Boxes per Case

6485 Rockets®, Special Ops™, Corded

50 Pairs per Box
4 Boxes per Case

LIMITED WARRANTY IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. **Exclusive Remedies:** damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damages, or liability, direct, indirect, incidental, special or consequential, arising out of a sale, use or misuse, or the inability to use products by the user.

DISTRIBUTED BY:



Printed on Recycled Paper



MOLDEX
Ideas that wear well.