



HEARING BANDS

NRR
22
dB



6500 Rock Band

THE COMFORTABLE, COST EFFECTIVE ALTERNATIVE TO EARMUFFS

The hearing band younger workers have been waiting to wear. Five exciting colors make the Rock Band popular with the new generation of workers. Two flexible arms distribute pressure evenly and the soft reusable pods gently cap off the ear canal. Appeal to all workers in search of a more comfortable hearing band. The Rock Band is not only the band younger workers want to wear, but also the perfect band for putting some excitement into a hearing conservation program.

FEATURES

- Soft, comfortable, reusable pods gently cap off the ear canal.
- Available in 5 exciting colors, each box comes with two of each color.
- Two flexible arms distribute pressure evenly for maximum comfort.
- Bright, fun colors appeal to the new generation of workers.
- Independently tested NRR 22 (Under-the-Chin).
- 100% PVC-Free.



Available in 5 exciting colors, each box comes with two of each color.



HEARING BANDS

PART # / DESCRIPTION	DISPLAY	CASE
6500 Rock Band	10 Bands per Box	5 Boxes

WARNING TO USER

1. Use this laboratory-derived attenuation data for comparison purposes only. The amount of protection afforded in field use often is significantly lower depending on how the protectors are fitted and worn.
2. Failure to follow all instructions could result in hearing loss or injury.
3. Failure to obtain a proper fit will reduce effectiveness of hearing protectors and could result in hearing loss or injury.
4. Hearing bands must only be used as part of a hearing conservation program that complies with applicable local safety and health regulations.
5. Overprotection can be dangerous. The wearer must be able to hear warning signals.
6. Wearers with hearing loss should exercise extreme caution.
7. It is the employer's responsibility to ensure that the type of hearing protector and its NRR is appropriate for the user in their particular workplace.
8. Use caution when working around machinery or other equipment to ensure neck cord does not become caught or entangled.
9. Failure to follow these warnings could result in serious injury or death.
10. Only use/wear under the chin.

MOLDEX TECHNICAL ASSISTANCE

Moldex provides all of the technical assistance required to set up a hearing protection program. For more information call +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512/550 or E-mail: tech@moldex.com or visit www.moldex.com.

DISTRIBUTED BY:

ATTENUATION DATA – UNDER-THE-CHIN

Tested According to ANSI Specs S3. 19-1974 Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	30.3	27.4	26.8	26.7	32.6	40.0	39.0	36.9	34.6	NRR 22	CSA BL
Standard Deviation (dB)	3.8	3.4	3.2	2.7	3.5	4.1	3.5	4.3	5.3		



MOLDEX-METRIC, INC.
 10111 West Jefferson Blvd.
 Culver City, CA 90232
 TEL: +1 (800) 421-0668 or
 +1 (310) 837-6500
 FAX: +1 (310) 837-9563
 E-mail: sales@moldex.com
 www.moldex.com

CANADIAN CUSTOMER SERVICE
 Tel: +1 (800) 421-0668, Ext. 550/512
 Fax: +1 (310) 837-9563



Printed on Recycled Paper