

Rockets®

REUSABLE EARPLUGS

NRR
27
dB



6400 Rockets, Uncorded
w/ Pocket-Pak



6405 Rockets, Corded
w/ Pocket-Pak



6420 Rockets, Cloth Cord
w/ Pocket-Pak

6404 Rockets,
Corded/Bagged



6415 Rockets,
Metal Detectable, Corded



NRR 27 PROTECTION

With an NRR 27 rating, the Rockets earplugs provide serious protection for most noisy environments. Tested independently in an accredited laboratory to ANSI S3.19-1974.

GET A GRIP

Rockets reusable earplugs are designed to give you a great grip. The easy grip handle lets them easily slip into the ear.

AIR CUSHIONED FOR COMFORT

The air bubble in the tip provides cushioned comfort for all-day wear. The soft, flexible flanges provide a superior seal and fit most size ear canals.

WASH AND WEAR AGAIN

Rockets earplugs can be washed and reused. Each pair comes with a Pocket-Pak® carrying case (except 6404 and 6415) to keep them clean when not in use. The smooth shape slides easily into your pocket. No sharp edges.

METAL DETECTABLE VERSION

Rockets also come in a metal detectable version which has the plug and cord independently detectable for added safety. The enclosed metal spring eliminates any exposed metal and the earplugs are corded to prevent earplug loss. The bright blue color is perfect for food processing applications.

FEATURES

- Independently tested NRR 27.
- Easy grip handle lets earplugs easily slip into ear.
- Air bubble in tip provides cushioned comfort.
- Earplugs can be washed and reused.
- Pocket-Pak carrying case provides hygienic storage of plugs between uses.
- Available in corded, uncorded, and corded metal detectable models.
- In the metal detectable version, the plug and cord are independently detectable for added safety.
- Look for the bright green color as a symbol of Moldex quality.
- 100% PVC-Free.



REUSABLE EARPLUGS



6480 Rockets Special Ops®
Uncorded w/ Pocket-Pak

6485 Rockets Special Ops®
Corded w/ Pocket-Pak

PART # / DESCRIPTION	DISPLAY	CASE
6400 Rockets, Uncorded w/ Pocket-Pak	50 Pairs per Box	4 Boxes per Case
6405 Rockets, Corded w/ Pocket-Pak	50 Pairs per Box	4 Boxes per Case
6404 Rockets, Corded/Bagged	50 Pairs per Box	4 Boxes per Case
6415 Rockets, Metal Detectable, Corded/Bagged	50 Pairs per Box	4 Boxes per Case
6420 Rockets, Cloth Cord w/ Pocket-Pak	50 Pairs per Box	4 Boxes per Case
6480 Rockets, Special Ops, Uncorded w/Pocket-Pak	50 Pairs per Box	4 Boxes per Case
6485 Rockets, Special Ops, Corded w/Pocket-Pak	50 Pairs per Box	4 Boxes per Case

ATTENUATION DATA

Tested According to ANSI Specs S3.19-1974 Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	34.3	35.3	36.8	34.7	35.5	40.5	37.5	40.3	44.4	NRR	CSA
Standard Deviation (dB)	4.1	4.4	5.1	3.1	3.4	3.7	3.8	6.2	3.8	27	AL

WARNING TO USER

- Rockets Reusable Earplugs must be fitted and worn correctly to provide effective protection.
- Reusable earplugs may deteriorate with use and should be examined for cracking or other deformations and replaced as necessary.
- Wash or clean hands before use. Plugs should be routinely washed with mild soap and warm water.
- CAUTION:** Remove with a slow twisting motion to break the seal. Due to the tight seal, rapid removal may damage eardrum.
- Use this laboratory-derived attenuation data for comparison purposes only. The amount of protection afforded in field use often is significantly lower depending on how the protectors are fitted and worn.
- Failure to follow all instructions could result in hearing loss or injury.
- Failure to obtain a proper fit will reduce effectiveness of hearing protectors and could result in hearing loss or injury.
- Rockets must only be used as part of a hearing conservation program that complies with applicable local safety and health regulations.
- Overprotection can be dangerous. The wearer must be able to hear warning signals.
- Wearers with hearing loss should exercise extreme caution.
- It is the employer's responsibility to ensure that the type of hearing protector and its NRR is appropriate for the user in their particular workplace.
- Use caution when working around machinery or any other equipment to ensure neck cord does not become caught or entangled.
- Failure to follow these warnings could result in serious injury or death.

MOLDEX TECHNICAL ASSISTANCE

Moldex provides all of the technical assistance required to set up a hearing protection program. For more information call +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512/550 or E-mail: tech@moldex.com or visit www.moldex.com.

Keep earplugs away from infants and small children as they may get caught in the windpipe and create a choking hazard.



DISTRIBUTED BY:

MOLDEX®
Ideas that wear well.™

MOLDEX-METRIC, INC.
10111 West Jefferson Blvd.
Culver City, CA 90232
TEL: +1 (800) 421-0668 or
+1 (310) 837-6500
FAX: +1 (310) 837-9563
E-mail: sales@moldex.com
www.moldex.com

CANADIAN CUSTOMER SERVICE
Tel: +1 (800) 421-0668, Ext. 550/512
Fax: +1 (310) 837-9563



Printed on Recycled Paper