

MOISTURIZED HEARING PROTECTION



GLIDE SOOTHERSTM Moisturizing Earplugs

MOISTURIZES FOR ALL DAY COMFORT

Glide Soothers' unique multi-curved stem rotates for a custom fit inside each ear canal. Combine that with the signature Soothers® soft comfortable outer surface that is so smooth, it doesn't irritate the ear canal. With its unique curved stem design, you simply push & twist to find your fit.

- ✓ **Moisturizes for all day comfort.**
- ✓ **Unique multi-curved stem rotates for a custom fit.**
- ✓ **Extra-soft, low-pressure foam for comfort and fit.**
- ✓ **Large handle on curved stem for easy insertion & removal.**
- ✓ **Cord can be attached at any desired length.**
- ✓ **Look for the streaks and swirls as a symbol of Moldex quality.**
- ✓ **100% PVC-Free, for reduced environmental impact.**



MODEL NUMBER	DESCRIPTION	DISPLAY QUANTITY	CASE QUANTITY	NRR
6980	Glide® Foam Soothers Twist In Earplugs without Cord	100 Pairs	4 Boxes	31 dB
6985	Glide® Foam Soothers Twist In Earplugs with Cord	100 Pairs	4 Boxes	31 dB
6886	Glide® Soothers Plugstation® Corded Foam Twist and Push-In Moisturized Earplug Dispenser	100 Pairs	4 Dispensers	31 dB



ATTENUATION DATA

Tested According to ANSI Specs S3.19-1974 by Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	35.5	37.0	42.5	39.9	39.5	40.0	40.5	43.4	45.6	NRR	CSA
Standard Deviation (dB)	4.5	4.2	4.9	4.1	3.3	4.3	3.4	3.8	3.9	31	AL

Always refer to warnings and instructions prior to use.

MOLDEX[®]
Ideas that wear well.[®]

SOOTHERS™

Moisturizing Earplugs



SOFT COMFORTABLE FIT

Moldex® Soothers® foam earplugs are made of extra-soft, extra light foam. Their tapered shape fits easily in the ear canal, allowing them to seal gently and snugly without uncomfortable pressure. Plus, the outer surface of the earplug is smooth, so it doesn't irritate the ear canal. They're so comfortable you'll forget you're wearing earplugs.

- ✔ Moisturizes for all day comfort.
- ✔ Highest independently tested NRR 33 dB.
- ✔ Extra-soft, low-pressure foam for comfort and fit.
- ✔ Tapered shape for easy insertion and removal.
- ✔ Non-irritating smooth surface
- ✔ Look for the streaks and swirls as a symbol of Moldex quality.
- ✔ 100% PVC-Free, for reduced environmental impact.

MODEL NUMBER	DESCRIPTION	DISPLAY QUANTITY	CASE QUANTITY	NRR
6680	Soothers® Uncorded	200 Pairs	10 Boxes	33 dB



ATTENUATION DATA

Tested According to ANSI Specs S3.19-1974 by Michael & Assoc., State College, PA.

Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000		
Mean Attenuation (dB)	37.5	36.7	42.2	40.3	39.3	42.3	44.6	46.6	45.9	NRR 33	CSA AL
Standard Deviation (dB)	5.5	4.4	3.5	3.2	2.8	3.0	3.1	2.8	2.8		

WARNING

1. Use these laboratory derived attenuation data for comparison purposes only. The amount of protection afforded in field use often is significantly lower depending upon how the protectors are fitted and worn.
2. Failure to follow all instructions and warnings could result in increased risk of hearing loss or serious injury or death.
3. Failure to obtain a proper fit will reduce effectiveness of hearing protectors and could result in increased risk of hearing loss, serious injury or death.
4. Over protection can be dangerous. The wearer must be able to hear warning signals.
5. Wearers with hearing loss should exercise extreme caution.
6. It is the employer's responsibility to ensure that the type of hearing protector and its rating is appropriate for the user in their particular workplace.
7. Use caution when working around machinery or any other equipment to ensure neck cord does not become caught or entangled.
8. Earplugs must only be used as part of a hearing conservation program that complies with applicable local safety and health regulations.
9. If irritation, redness or discomfort occurs, discontinue use and consult a licensed health practitioner.



Keep earplugs away from infants and small children as they may get caught in the windpipe and create a choking hazard.

MOLDEX TECHNICAL ASSISTANCE

Moldex provides all of the technical assistance required to set up a hearing protection program. For more information call +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512, or email: tech@moldex.com or visit www.moldex.com.

MOLDEX-METRIC, INC.

10111 Jefferson Blvd., Culver City, CA 90232
 TEL: +1 (800) 421-0668 or +1 (310) 837-6500
 EMAIL: sales@moldex.com
 www.moldex.com

U.S. & CANADA CUSTOMER SERVICE
 TEL: +1 (800) 421-0668, Ext. 550

For user instructions refer to packaging or visit
<https://www.moldex.com/resources/instructional-resources/fitting-instructions-hearing/>



Made in USA
 Hecho en USA
 Fabriqué aux EU.



PVC FREE
 Libre de PVC
 PVC Gratuit

Moldex®, Ideas that wear well®, Glide®, Soothers®, PlugStation®, the PVC-Free logo and the random colored streaks and swirls are registered trademarks of Moldex.

Always refer to warnings and instructions prior to use.